

Figure 1. Routine *Legionella* testing: A multifactorial approach to performance indicator interpretation*^{oΔ}

Concentration indicates that *Legionella* growth appears:

Uncontrolled	Poorly Controlled	Well Controlled			
≥10 CFU/mL [†] in potable water OR ≥100 CFU/mL in cooling towers	1.0–9.9 CFU/mL in potable water OR 10–99 CFU/mL in cooling towers	Detectable to 0.9 CFU/mL in potable water OR Detectable to 9 CFU/mL in cooling towers	No <i>Legionella</i> detected in a single round of testing	No <i>Legionella</i> detected in multiple rounds of testing	No <i>Legionella</i> detected in multiple rounds of testing with methods that detect viable and non-viable bacteria of any <i>Legionella</i> species

Change in concentration over time indicates that *Legionella* growth appears:

Uncontrolled	Poorly Controlled	Well Controlled			
100-fold or greater increase in concentration (e.g., 0.05 to 5 CFU/mL)	10-fold increase in concentration (e.g., 0.05 to 0.5 CFU/mL)	<i>Legionella</i> concentration steady (e.g., 0.5 CFU/mL for two consecutive sampling rounds)	No <i>Legionella</i> detected in a single round of testing	No <i>Legionella</i> detected in multiple rounds of testing	No <i>Legionella</i> detected in multiple rounds of testing with methods that detect viable and non-viable bacteria of any <i>Legionella</i> species

Extent indicates that *Legionella* growth appears:

Uncontrolled	Poorly Controlled	Well Controlled			
Detection in multiple locations AND a common source location [‡] OR Detection across many locations within a water system	Detection in a common source location that serves multiple areas OR Detection in more than one location within a water system	Detection in a few of many tested locations within a water system	No <i>Legionella</i> detected in a single round of testing	No <i>Legionella</i> detected in multiple rounds of testing	No <i>Legionella</i> detected in multiple rounds of testing with methods that detect viable and non-viable bacteria of any <i>Legionella</i> species

Type[¥] of *Legionella* (species and serogroup) associated with Legionnaires' disease:

Highly Associated	Less Associated
<i>L. pneumophila</i> serogroup 1; Non-Lp1 <i>L. pneumophila</i> ; Presence of multiple different <i>Legionella</i> species or serogroups	Any non- <i>pneumophila</i> <i>Legionella</i> species including “blue-white” fluorescent <i>Legionella</i>

* This figure is intended for use during routine testing of potable water and cooling towers only. Due to their ability to rapidly grow and spread *Legionella*, any detection of viable *Legionella* in a hot tub or decorative fountain should prompt a response, including a review of the water management program and corrective actions. Test results are performance indicators and are not a measure of risk of human illness. This figure is not intended for use if a building or device is associated with Legionnaires' disease (LD) cases or an outbreak.

^o See “Routine testing for *Legionella*” for guidance regarding suggested response activities. Comparable results may lead to different suggested response activities when other factors are considered (e.g., if there is evidence of poorly controlled growth at a healthcare facility).

^Δ Considering the type of *Legionella* identified along with other *Legionella* testing performance indicators provides a clearer picture of water system control than the results of any single indicator. For example, facility owners and operators may consider implementing immediate interventions for a healthcare facility with: A. detectable but <10 colony-forming units per milliliter (CFU/mL), B. non-Lp1 *Legionella pneumophila*, C. observed at steady concentrations, but D. detected at multiple distal locations including a central water heater.

[†] Concentrations expressed as CFU/mL are for test results generated by traditional spread plate culture methods. If other test methods are used, consult testing lab or manufacturer instructions for appropriate interpretation.

[‡] Common source location examples include water heaters, hot water returns, storage tanks, and cooling tower basins.

[¥] If a facility has a history of associated LD cases, then sequencing isolates obtained during routine testing may provide performance indicators regarding outbreak strain persistence (if that strain is detected).



CS321985-H